

Treadmill Console replacement instructions

1. Remove the covers above handle bars on the right and left. They are held on by 6 screws (4 on the outside and 2 on the inside).



2. Disconnect the three harnesses (two on the right side and one on the left).
3. Remove the four bolts (two on each side) that hold the console to the uprights.
4. Remove console and install the new console.
5. Insert and tighten the four console bolts and plug in the three harnesses.
6. Put the covers back on.
7. Turn power on and **CALIBRATE**.