

Elliptical Console replacement instructions

1. Turn off power switch or unplug power supply.
2. Remove the four Phillips head screws that hold the console to the console mast.



3. Unplug the wiring from the back of the console.
4. Plug in wiring into new console.
5. Mount the console to the mast using the four Phillips head screws.
6. Calibrate incline.