

## CALIBRATION PROCEDURE FT 94

- a) Turn on power.
- b) Press and hold "START" and "FAST" button at the same time.
- c) Set the SAFETY KEY on console, all windows will appear blank.
- d) Km/Mile Mode: Press "FAST/SLOW" button to exchange to the metric measure in display and the value is km.
- e) Press "ENTER" button to memorize above setting and enter next section of setting mode.
- f) Set wheel size: Press "FAST" or "SLOW" button to adjust wheel size in 1.85.
- g) Press "ENTER" button to memorize above setting and enter next section of setting mode.
- h) Set Min. speed: Press "FAST" or "SLOW" button to adjust speed 1.0.
- i) Press "ENTER" button to memorize above setting and enter next section of setting mode.
- j) Set high speed: Press "FAST" or "SLOW" button to adjust speed 10.0.
- k) Press "ENTER" button to memorize above setting and enter next section of setting mode.
- l) Set High incline position: Press "UP" or "DOWN" button to adjust incline in 10.
- m) Press "START" button to memorize all value, the treadmill will calibrate automatically.
- n) After calibrating, treadmill will reset then enter "READY MODE".